

**AQUATICA™**



**Digital**

**Nikon**

**Type 3** lens chart

**Aquatica housings for:  
Nikon D3/D3x/D3s  
Nikon D700**

# AQUATICA™

## Digital

TYPE 3 FOR NIKON

For Nikon D3s/D3x/D3 & D700

### 4" dome port lens chart (# 18410)

Camera Lens	EXTENSION	Dome Shade	GEAR
			Zoom (Z) or Focus (F)
Nikon AF 10,5mm f/2,8 G ED DX Fisheye	(*3)	Built in	(F) 18699
Nikon AF-D 16mm f/2,8 Fisheye	(*2)		
Sigma 10mm F2.8 EX DC HSM Fisheye	(*1)(*3)		
Sigma 15mm f/2.8 Fisheye	(*1)		
Tokina AT-X 10-17mm f/3.5-4.5 AF DX Fisheye	18456 (*3)	Built in	(Z) 18717
Tokina AT-X 10-17mm f/3.5-4.5 AF DX Fisheye + 1.4x converter	18453	Built in	(Z) 18731

(\*1) Due to the length of the lens shade, it is impossible to use this lens with the # 18410 dome port

(\*2) Due to the minimum focusing distance being too far, it is impossible to use this lens with the # 18410 dome port

(\*3) This is a DX lens and will not give a complete image on a FX format

### 6" dome port lens Chart (#18409)

Camera Lens	EXTENSION	Dome Shade	GEAR
			Zoom (Z) or Focus (F)
Nikon AF 16mm f/2.8 D	Not Required	18484	(F)18689
Nikon AF 20mm f/2.8	Not Required	18484	(F)18674
Nikon AF 24mm f/2.8 D	Not Required	18484	(F)18686
Nikon AF 28mm f/2.8 D	Not Required	18484	(F)18686
Nikon AF 20-35mm f/2.8 D (*1)	18453	18484	(Z)18675
Sigma 8mm F3.5 EX DG Circular Fisheye	18456	Not Required	Use in AF
Sigma 15mm f/2.8 FISHEYE	Not Required	18484	(F)18715
Tokina AT-X 10-17mm f/3.5-4.5 AF DX Fisheye + 1.4x converter	18453	18484	(Z) 18731

(\*1) +4 diopter needed for this dome port

# AQUATICA™ TYPE 3 FOR NIKON

## Digital

For Nikon D3/D3s/D3X & D700

### 8" dome port lens chart (# 18405)

Camera Lens	EXTENSION	Dome Shade	Zoom (Z) or Focus (F) GEAR
Nikon AF 14mm f/2.8D ED	18456	18480	(F) 18693
Nikon AF 16mm f/2.8 D	Not Required	18480	(F) 18689
Nikon AF 18mm f/2.8	18456	18480	(F) 18680
Nikon AF 20mm f/2.8	Not Required	18480	(F) 18674
Nikon AF 24mm f/2.8 D	Not Required	18480	(F) 18686
Nikon AF 28mm f/2.8 D	Not Required	18480	(F) 18686
Nikon AF-S 14-24mm f/2.8G ED NIKKOR (*2)	18458	18480	(Z) 18722
Nikon AF-S 16-35mm f/4 G ED VR DX	18458	18480	(Z) 18728
Nikon AF-S 17-35mm f/2.8D IF-ED	18457	18480	(Z) 18690
Nikon AF 20-35mm f/2.8 D (*1)	18453	18480	(Z) 18675
Nikon AF-S 24-70mm f/2.8 G	18454	18480	(Z) 18722
Nikon AF-S 28-70mm f/2.8 D (*1)	18458	18480	(Z) 18723
Sigma 8mm F3.5 EX DG Circular Fisheye	18456	Not Required	Use in AF
Sigma 14mm f/2.8 EX ASPHERICAL HSM	18462	18480	(F) 18697
Sigma 15mm f/2.8 FISHEYE	Not Required	18480	(F) 18715
Tokina AT-X 10-17mm f/3.5-4.5 AF DX Fisheye + 1.4x converter	18453	18480	(Z) 18731

(\*1) +3 diopter needed for 8" dome port

(\*2) Older pre 2008 port may not fit due to the oversized nature of this lens.

Updated December 13, 2011

# AQUATICA™ TYPE 3 FOR NIKON

## Digital

For Nikon D3s/D3x/D3 & D700

### 9.25" dome port lens chart (# 18407)

BK-7 coated mineral glass

Camera Lens	EXTENSION	Dome Shade	GEAR Zoom (Z) or Focus (F)
Nikon AF 14mm f/2.8D ED	18453	Built in	(F)18693
Nikon AF 16mm f/2.8 D	Not Required	Built in	(F)18689
Nikon AF 18mm f/2.8	18456	Built in	(F)18680
Nikon AF 20mm f/2.8	Not Required	Built in	(F)18674
Nikon AF 24mm f/2.8 D	Not Required	Built in	(F)18686
Nikon AF 28mm f/2.8 D	Not Required	Built in	(F)18686
Nikon AF-S 14-24mm f/2.8G ED NIKKOR (*2)	18458	Built in	(Z) 18722
Nikon AF-S 16-35mm f/4 G ED VR DX	18458	Built in	(Z) 18728
Nikon AF-S 17-35mm f/2,8D IF-ED	18458	Built in	(Z)18690
Nikon AF-S 17-55MM f/2.8 ED-IF	18457	Built in	(Z)18711
Nikon AF 20-35mm f/2.8 D (*1)	18453	Built in	(Z)18675
Nikon AF-S 24-70mm f/2.8 G	18454	Built in	(Z) 18722
Nikon AF-S 28-70mm f/2.8 D (*1)	18458	Built in	(Z) 18723
Sigma 14mm f/2.8 EX ASPHERICAL HSM	18462	Built in	(F)18697
Sigma 15mm f/2.8 FISHEYE	Not Required	Built in	(F)18715
Tokina AT-X 10-17mm f/3.5-4.5 AF DX Fisheye + 1.4x converter	18453	Built in	(Z) 18731

(\*1) +3 diopter needed for 9.25" dome port

(\*2) Older pre 2008 port may not fit due to the oversized nature of this lens.

Updated December 13, 2011

# AQUATICA™

## Digital

TYPE 3 FOR NIKON

For Nikon D3s / D3x / D3 & D700

### Macro port lens chart (# 18426 & 18428)

The 18426 AF/MF Macro Port is equipped with a focus knob that allows manual focusing when combined with a focus gear on the lens

The 18428 AF Macro port was designed to be operated in Autofocus mode

Camera Lens	18428 & 18426 EXTENSION	18426 GEAR	18428 GEAR
Nikon AF-D Micro 60mm F2.8 (*4)	Not Required	(F)18670/(*)18682	Use in AF only
Nikon AF-S Micro 60mm f/2.8G ED <b>NEW</b>	Not Required	(F) 18728	Use in AF only
Nikon AF-S Micro 85mm f/3.5 G ED VR <b>NEW</b> (*3)	Not Required	(F) 18728	Use in AF only
Nikon AF-D Micro 105mm F2.8 (*5)	18453	(F)18679/(*)18683	Use in AF only
Nikon AF-S Micro 105MM f/2.8 G ED-IF VR, <b>NEW</b>	18453	(F)18712.1	Use in AF only
Nikon AF Micro 200mm F/4 D	18454	(F)18656	Use in AF only
Nikon AF Micro 70-180 mm f/4.5-5. 6D ED	18454	(F)18691/(Z)18692	Use in AF only
Sigma 50mm F2.8 EX MACRO	Not Required	(F)18701	Use in AF only

(\*3) This is a DX lens and will not give a complete image on a FX format

(\*4) Auto/manual focus selector available 18682, (\*5) Auto/manual focus selector available 18683

Updated December, 2011